










## SUPPLIED HARDWARE

	DESCRIPTION	QUANTITY
i	 2 1/2" x 5/16" Button Head Bolt	4
ii	 5/16" Lock Nut	4
iii	 5/16" Flat Washer	10
iv	 #8 x 1 3/4" Robertson Flat Head Screw	8
v	 3/8" Flat Washer	2
vi	 4 1/2" x 1/4" Lag Screw	2
vii	 1/2" Flat Washer	2
viii	 3" Clear Plastic Spacer	2

## REQUIRED TOOLS:


- 1) 1/2" Wrench
- 2) Pliers
- 3) Robertson Screwdriver

## SUPPLIED PARTS



**CAUTION!** CEDAR IS VERY SOFT. HANDLE WITH CARE. IT IS EASILY MARKED EVEN IF STAINED. BE CAREFUL WHEN INSERTING SCREWS. IF YOU SLIP & HIT THE CEDAR WITH A SCREWDRIVER, YOU WILL PUNCTURE THE SURFACE. TO ERASE SCRATCH MARKS ON UNSTAINED CEDAR, SAND WITH 120 GRIT SANDPAPER.

**READ INSTRUCTIONS THROUGH ONCE BEFORE BEGINNING ASSEMBLY.**



### STEP 1: Connect Legs to Seat.

Connect each Leg to Seat by first inserting bolt "i" with washer "iii" into pre-drilled hole on lower part of outside of Leg. Sandwich spacer "viii" between the Leg and the Seat and pass bolt through it. Pass bolt through pre-drilled hole on Seat. Place washer "v" on bolt and secure with lock nut "ii".

### STEP 2: Connect the Kickplate.

Insert all eight screws "iv" into Kickplate until they barely protrude through the other side BEFORE attaching Kickplate to Legs. Then attach Kickplate to Legs by inserting screws into pre-marked holes. The kickplate should butt up against the bottom of the seat.

### STEP 3: Connect Arm Paddles to Legs.

Insert washer "iii" into pre-drilled hole on rotator piece on Arm Paddle. Affix Arm Paddle to Leg by first inserting bolt "i" with washer "iii" into pre-drilled hole on upper part of inside of Leg, and then through rotator piece on Arm Paddle. Be sure to sandwich washer "vii" in between the Leg and rotator piece on Arm Paddle. Secure with lock nut "ii". Repeat for both Arm Paddles.

**STEP 4: Connect the Back to the Arm Paddles.** Insert lag screw "vi" through washer "iii" and then insert into pre-drilled hole on back of Arm Paddle. Sandwich washer "iii" between Arm Paddle and Back support with pre-drilled hole. Gently insert lag screw into Back support and tighten. Repeat for both Arm Paddles.



**STEP 6: VERY IMPORTANT!!! GET FAVORITE BEVERAGE AND ENJOY!**

**HELPFUL HINT:** Do not over-tighten bolts or screws. The chair should fold & unfold easily.